

Compatible with the following Goalrilla systems:

CV series (B3333W-1, B3222W-1, B3010W-1, B3101W-1, B3011W-1)

GS series (B4003W-1, B5003W-1, B5002W-1, B5000W-1)

FT series (B3015W-1, B3016W-1, B3017W-1)

LOCKING ACTUATOR HANDLE


MODEL NO.
B2633W-1

Key#	Part #	Description	Qty.
1	4A-8937-00	Actuator Handle	1
2	7B-6255-00	Pull Pin	1
3	7Q-1010-00	Lock	1
4	7Q-1011-00	Key	2

NORMAL OPERATION

1. Slide the Actuator Handle (**#1**) onto the shaft on the back of the Actuator. Line up the hole in the shaft with the hole in the Actuator Handle and insert the Pull Pin (**#2**) to secure. See **Detail A**.


NOTE: This handle can be used as a regular handle or a locking handle. If you are away for an extended period of time, the actuator can be locked to prevent height adjustment. See the locking position instructions below.



LOCKING POSITION

1. Set the rim to the desired height, usually 10ft. This will prevent most from dunking on it.
2. Rotate the Actuator Handle (**#1**) until the holes face the front and back, and remove the Pull Pin (**#2**). See **Detail A**.
3. Flip the Actuator Handle (**#1**) upside down so the **hand grip faces up** and is positioned between the post ears. See **Detail B**.
4. Slide the Handle (**#1**) onto the Actuator shaft, align the holes, and slide the shackle on the Lock (**#3**) through the handle and shaft. See **Detail B**.

NOTE: You can keep the pull pin on the lock to prevent it from getting removed or lost. To do so, pass the ring on the pull pin through the lock's shackle and secure the lock.



ESCALADE
SPORTS

Please Do not return this product to the store!

Contact Escalade® Sports customer service department at:

Phone: 1-800-467-1421

E-mail: basketball@escaladesports.com

90 DAY LIMITED WARRANTY

WARRANTY COVERAGE: Escalade® Sports warrants to the original Consumer Purchaser that any Product of its manufacture is free from defects in material and workmanship. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL OR WORKMANSHIP.

NOT COVERED BY THIS WARRANTY

Any merchandise subjected to abuse, negligence, improper installation, vandalism, acts of God, alteration of product, or any other events beyond the control of Escalade® Sports.