

ASSEMBLY INSTRUCTIONS

FUSION PRO PT1800

TABLE TENNIS TABLE





DO NOT ASSEMBLE THIS TABLE WITHOUT READING THIS MANUAL TO FAMILIARIZE YOURSELF WITH THE ASSEMBLY PROCESS FIRST.

PLEASE RETAIN INSTRUCTIONS FOR FUTURE PARTS IDENTIFICATION.

TOOLS REQUIRED FOR ASSEMBLY (Not Included):

SCREW DRIVER and two ADJUSTABLE WRENCHES

PARTS INDENTIFIER and ASSEMBLY PARTS

P1 QUANTITY: 4	P2 QUANTITY: 2	P3 QUANTITY: 4	P4 QUANTITY: 2
	7	(2 PRE-INSTALLED)	Drince'
Bolt, 6x55mm Hex Head	Safety Catch with Nut	Bracket, Metal	Brace, Center Leg Support
P5 QUANTITY: 4	P6 QUANTITY: 2	P7 QUANTITY: 2	P8 QUANTITY: 4
	(PRE-INSTALLED)	(PRE-INSTALLED)	
Bending Linkage Support	1.25" Inner Leg	2" Outer Leg	Bolt, 6x70 mm Hex Head
P9 QUANTITY: 8	P10 QUANTITY: 24	P11 QUANTITY: 8	P12 QUANTITY: 8
	(12 PRE-INSTALLED)		
Lock Nut, 8mm	Screw, 4 X14mm Hex Head	Washer, 8mm	Bolt, 8 x 70mm Hex Head
P13 QUANTITY: 8	P14 QUANTITY: 16	P15 QUANTITY: 8	P16 QUANTITY: 1
Bushing	Washer, 6mm	Lock Washer, 6mm	Set, Net and Post
P17 QUANTITY: 1	P18 QUANTITY: 4	P19 QUANTITY: 2	P20 QUANTITY: 2
(PRE-INSTALLED)	(PRE-INSTALLED)		
Safety Strap	Corner Cap	Wheel Assembly, Non-Locking	Wheel Assembly, LOCKING

P21 QUANTITY: 4

Label, Fusion Pro Apron


ASSEMBLY INSTRUCTIONS

We recommend that at least two strong adults work together to assemble this table.

The table will be assembled upside down and then turned over onto its legs.

This is a very heavy table and turning it over will require at least two strong adults.

We suggest that you use the bottom carton as a clean flat work area to protect the table.



STEP 1 (FIG. 1)

* Attach one wheel without lock (#P19) and one wheel with lock (#P20) to the Inner Leg (#6). Please repeat the same steps for the other Inner Legs. See Fig.1 above.


NOTE: Make sure one of each wheel w/o lock (#P19) and one wheel with lock(#P20) are attached to each Inner Leg.


- * Make sure one Pre-installed Metal Bracket (#P3) is attached over per Inner Leg (#P6).
- * Attached the two Metal Brackets (#P3) over the ends of the Inner Leg (#P6) using six Screws (#P10) per bracket. (as shown on Fig. 1)

NOTE: Make sure the slots in the brackets are facing the center.

* Repeat the above steps for the other table half.

ASSEMBLY INSTRUCTIONS (continued)






STEP 2 (FIG. 2)

- Attach one end of the Bending Linkage Support (#P5) to the Outer Leg (#P7) with one Bolt (#P8), one Bushing (#P13), two Washers (#P14) and one Locking Nut (#P15) per Outer Leg. See 2-A.
- Then attach the other end of the Bending Linkage Support (#P5) to the Inner Leg (#P6) using one Bolt (#P1), one Bushing (#P13), two Washers (#P14) and one Locking Nut (#P15) per Tube. See 2-B.
- Repeat the same assembly for the other Bending Linkage Supports.
- Attaching the Bending Linkage Support (#P5) to the Inner Leg might seem a little complicated so we have prepared a video that demonstrates the assembly process at each leg. You may access the video by scanning the "QR" code below with your smartphone or visiting the DMI Sports link and selecting the "Prince Fusion Table Assembly Instructions"



ASSEMBLY INSTRUCTIONS (continued)



STEP 3 (FIG. 3)

* With the logo upside-down, attach one Leg Metal Spreader (#P4) to the Inner Leg (#P6) with two Bolts (#P12), two Washers (#P11) and two Nuts (#P9) per Spreader. See Fig. 3.

Repeat the same assembly for other side.


- * Before turning the table over, make sure to push the Inner Leg (#P6) towards the player end of the table in order to engage the table stop.
- * At least two strong adults are required to turn this table over.
- * Do not let the full weight of table rest on its side or its legs, or this may damage the table.
- * One person should stand at each end of the table and turn the table over completely so that it rests on its legs.

ASSEMBLY INSTRUCTIONS (continued)



STEP 4 (FIG. 4)

- * Attach one Safety Catch (#P2) to the Inner Leg (#P6) with one Nut (attached to the Safety Catch) per side. Attach the Fusion Pro label to the end of the side apron. See Fig.4
- * Repeat the above step for the other side.



This is a very heavy table by design. An adult should always raise and lower table sides for storing.

To close the table, raise the end of the table without the net and posts. The end legs should collapse toward the underside of the table (but will not lie flat). Continue raising the end until table surface is vertical and safety catch is engaged.

Use safety strap to secure.

To open the table, release the safety strap and raise the red safety catch. With the safety catch up the table top is now ready to be lowered.

This table is for INDOOR USE only.



RECOMMENDATION OF USE AND PRECAUTIONS

Anyone using or handling this table tennis table must always follow the illustrations and the operation instructions.

- 1. <u>Handling the table, (assembly, open, close, or to store) should always be done by two adults</u> to prevent accident or injury.
- 2. Be sure that no persons, pets or objects are in the way of the table when opening or closing.
- 3. Do not put heavy objects on the table.
- 4. Do not sit on the table.
- 5. Do not clean the table with solvents or any other aggressive product because it could damage the paint finish.
- 6. Do not use sharp objects on the table.
- 7. If the table is used for purposes other than playing table tennis, cover the surface to prevent damage.
- 8. The functioning and storage of this product should always be supervised by an adult.
- 9. Do not store or handle the table on an unstable floor surface.
- 10. If safety device malfunction occurs, secure table top until the problem is solved.
- 11. To extend the life of this table, (outdoor table or indoor table) protect it from moisture or severe climate changes.

CARE AND MAINTENANCE

Cleaning your table

Use a soft damp (not wet) cloth only. DO NOT USE ANY CHEMICALS OR ABRASIVE OR CLEANING PRODUCTS on the playing surface.

Maintenance of your table

All moving parts must be periodically oiled including the pivot points. This will insure ease of use and safety of your table. Once or twice per year or when folding and unfolding action is not smooth.

This table must be stored indoors to avoid damage to the surface. Dampness and temperature changes can cause wood play surface to warp, swell or blister.

Please visit:

http://www.dmisports.com/table-tennis/

for information on the full line of Prince table tennis accessories.

DMI Sports, Inc.
Fort Washington, PA USA
www.dmisports.com